
## Headlamps LED From January 2011



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Wiring Diagram




## Vehicle Electrical System Control Module

- J519 Vehicle Electrical System Control Module
- SD6 Fuse 6 (On Fuse Panel D) SD7 Fuse 7 (On Fuse Panel D)
- SD8 Fuse 8 (On Fuse Panel D)
- SD9 Fuse 9 (On Fuse Panel D)
- T17c 17-Pin Connector
- T17d 17-Pin Connector
- T17e 17-Pin Connector
- 44 Ground Connection on A-Pillar, Lower Left
- (369) Ground Connection 4 (in Main Wiring Harness)
- \* Refer to Applicable Wiring Diagram for Fuse Positions

## ( **J**519 ¥T32c ST<sub>2</sub> SC8 0.35 0.35 T4af T4af /1 LIN **1**4 ( E<sub>1</sub> E314 E315 E680 E20 0.35 (199) Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantse or according liability with respect to the correctness of information in this document 9ht black = red = red = brown = green = blue = grey = lilac (45) = lilac = yellow 21 22 23 24 25 = orange or 4G2-033030420 = pink


## Light Switch, Vehicle Electrical System Control Module

- E1 Light Switch
- E20 Instrument Panel and Switch Illumination Dimmer Switch
- E314 Rear Fog Lamp Button
- E315 Fog Lamp Button
- E680 Night Vision System Button
- J519 Vehicle Electrical System Control Module
  - K4 Position Lamp Indicator Lamp
- K13 Rear Fog Lamp Indicator Lamp
- K17 Fog Lamp Indicator Lamp
- L9 Headlamp Switch Illumination Bulb
- ST2 Fuse Panel 2
- SC8 Fuse 8 (On Fuse Panel C)
- T4af 4-Pin Connector
- T32c 32-Pin Connector
- 45 Ground Connection Behind Instrument Panel, Center
- 199 Ground Connection 3 (in Instrument Panel Wiring Harness)
- \* Refer to Applicable Wiring Diagram for Fuse Positions



Left LED Headlamp Power Output Module 2, Vehicle Electrical System Control Module, Left Daytime Running Lamp and Position Lamp LED Module, Left Front Turn Signal Bulb, Left Front Side Marker Lamp Bulb

- A32 Left LED Headlamp Power Output Module 2 J519 Vehicle Electrical System Control Module
- L176 Left Daytime Running Lamp and Position Lamp LED Module
- M5 Left Front Turn Signal Bulb
- M33 Left Front Side Marker Lamp Bulb
- T14g 14-Pin Connector, In the Headlamp
- T14h 14-Pin Connector, In the Headlamp
- T16b 16-Pin Connector
- T17c 17-Pin Connector
- T17e 17-Pin Connector
- 44 Ground Connection on A-Pillar, Lower Left
- (367) Ground Connection 2 (in Main Wiring Harness)
  - \* For USA Only
  - \*2 From June 2011



Left LED Headlamp Power Output Module 1, Vehicle Electrical System Control Module, Left Stationary Cornering Lamp, Left Front Turn Signal Bulb 2

- A31 Left LED Headlamp Power Output Module 1
  A33 Left LED Headlamp Power Output Module 3
- A34 Left LED Headlamp Power Output Module 4 J519 Vehicle Electrical System Control Module
- M51 Left Stationary Cornering Lamp
- M92 Left Front Turn Signal Bulb 2
- T14h 14-Pin Connector, In the Headlamp
- T16b 16-Pin Connector
- T17c 17-Pin Connector
- (367) Ground Connection 2 (in Main Wiring Harness)
  - For USA Only
- \*2 From June 2011

= white = black = red


= red

= brown = green = blue = grey = lilac = lilac = yellow

= orange

= pink

Wiring Diagram



Left LED Headlamp Power Output Module 1, Left Headlamp Temperature Sensor 1, Vehicle Electrical System Control Module, Left Low Beam Headlamp Bulb, Left High Beam Headlamp Bulb, Left Headlamp Range Control Adjustment Motor, Left Low Beam Headlamp Reflector Motor, Left Headlamp Fan

- A31 Left LED Headlamp Power Output Module 1
- G702 Left Headlamp Temperature Sensor 1
- J519 Vehicle Electrical System Control Module
  - 29 Left Low Beam Headlamp Bulb
- M30 Left High Beam Headlamp Bulb
- T6ax 6-Pin Connector, In the Headlamp
- T14f 14-Pin Connector, In the Headlamp
- T16b 16-Pin Connector
- T16c 16-Pin Connector
- T17c 17-Pin Connector
- V48 Left Headlamp Range Control Adjustment Motor
- V294 Left Low Beam Headlamp Reflector Motor
- V407 Left Headlamp Fan

= white = black = red = red = brown = green = blue = grey = lilac = lilac = yellow


= orange

= pink

or


rs

(in Main Wiring Harness)



Right LED Headlamp Power Output Module 2, Vehicle Electrical System Control Module, Right Daytime Running Lamp and Position Lamp LED Module, Right Front Turn Signal Bulb, Right Front Side Marker Lamp Bulb

- Right LED Headlamp Power Output Module 2 J519 Vehicle Electrical System Control Module
- L177 Right Daytime Running Lamp and Position Lamp LED Module
- Right Front Turn Signal Bulb
- Right Front Side Marker Lamp Bulb
- T14g 14-Pin Connector, In the Headlamp T14h 14-Pin Connector, In the Headlamp
- 16-Pin Connector
- T17c 17-Pin Connector
- T17e 17-Pin Connector
- 43 Ground Connection on A-Pillar, Lower Right
- Ground Connection 14 (in Main Wiring Harness)
  - For USA Only
  - From June 2011



Right LED Headlamp Power Output Module 1, Vehicle Electrical System Control Module, Right Stationary Cornering Lamp, Right Front Turn Signal Bulb 2

```
A27 Right LED Headlamp Power Output Module 1
A29 Right LED Headlamp Power Output Module 3
A30 Right LED Headlamp Power Output Module 4
J519 Vehicle Electrical System Control Module
M52 Right Stationary Cornering Lamp
M93 Right Front Turn Signal Bulb 2
T14h 14-Pin Connector, In the Headlamp
T16k 16-Pin Connector
T17c 17-Pin Connector

379 Ground Connection 14 (in Main Wiring Harness)
```

For USA Only

\*2 From June 2011


100

101

102

103

Wiring Diagram



107

108

109

110

111


112

4G2-033090420

Right LED Headlamp Power Output Module 1, Right Headlamp Temperature Sensor 1, Vehicle Electrical System Control Module, Right Low Beam Headlamp Bulb, Right High Beam Headlamp Bulb, Right Headlamp Range Control Adjustment Motor, Right Low Beam Headlamp Reflector Motor, Right Headlamp Fan

```
A27 Right LED Headlamp Power Output Module 1
G704 Right Headlamp Temperature Sensor 1
J519 Vehicle Electrical System Control Module
M31 Right Low Beam Headlamp Bulb
M32 Right High Beam Headlamp Bulb
G-Pin Connector, In the Headlamp
T14f 14-Pin Connector, In the Headlamp
T16k 16-Pin Connector
T17e 17-Pin Connector
V49 Right Headlamp Range Control Adjustment Motor
V295 Right Low Beam Headlamp Reflector Motor
V408 Right Headlamp Fan
```

ws = white
sw = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
vi = lilac
ge = yellow
or = orange
rs = pink



Left Rear Level Control System Sensor, Left Front Level Control System Sensor, Headlamp Range Control Module, Vehicle Electrical System Control Module

- G76 Left Rear Level Control System Sensor
  G78 Left Front Level Control System Sensor
  J431 Headlamp Range Control Module
  J519 Vehicle Electrical System Control Module
  ST1 Fuse Panel 1
  SC8 Fuse 8 (On Fuse Panel C)
- T4at 4-Pin Connector
  T4s 4-Pin Connector
  T17g 17-Pin Connector
  T26 26-Pin Connector
- \* Refer to Applicable Wiring Diagram for Fuse Positions
- \*2 Data Bus Wire (CAN Bus)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

ws = white
sw = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
vi = lilac
ge = yellow
or = orange
rs = pink

128

129

130

131

132

133

134

135


136

137

138

139

[4G2-033110420]



Vehicle Electrical System Control Module, Data Bus on Board Diagnostic Interface, Comfort System CAN Bus High Wire Junction, Extended CAN Bus High Wire Junction, Comfort System CAN Bus High Wire Junction 2

J519 Vehicle Electrical System Control Module
J533 Data Bus on Board Diagnostic Interface
T16c 16-Pin Connector
T32b 32-Pin Connector
T46a 46-Pin Connector
T46b 46-Pin Connector
TV34 Comfort System CAN Bus High Wire Junction
TV38 Comfort System CAN Bus Low Wire Junction
TV41 Extended CAN Bus High Wire Junction
TV42 Extended CAN Bus Low Wire Junction
TV40 Comfort System CAN Bus High Wire Junction
TV80 Comfort System CAN Bus High Wire Junction 2
TV83 Comfort System CAN Bus Low Wire Junction 2
B108 CAN Bus Extended High Connection 1 (in Main Wiring Harness)

CAN Bus Extended Low Connection 1 (in Main Wiring Harness)

\* Data Bus Wire (CAN Bus)

= white

= black

green

= grey = lilac = lilac = yellow

= orange

= pink

or

rs

= blue

= red = red = brown